

Tension Meter

Series: MZ-422

Model: MZ1-422
MZH-422
MZB1-422

SCHMIDT
control instruments



Edition MZ1-422 01.E




Software

Tension Inspect 3

Version: TI3
TI3-4
TI3-8
TI3-16
TI3-20
TI3-24

Instruction Manual

Valid as of: 01.05.2020 • Please keep the manual for future reference!



SCHMIDT · 1ST IN TENSIONMETERS WORLDWIDE

Contents

1	Warranty and Liability	3
1.1	Notices within the Operating Instructions	3
1.2	Responsibilities of the Operating Company	3
1.3	Responsibilities of the Personnel	3
1.4	Informal Safety Measures	4
1.5	Training of the Personnel	4
1.6	Intended Use	4
1.7	Dangers in Handling the Device	4
1.8	Copyright	4
1.9	Declaration of Conformity, RoHs II and WEEE Registration	4
2	Available Models	5
2.1	General Information	5
2.1.1	Available MZ Models with RS-422 Interface	6
2.1.2	Available MZH Models with RS-422 Interface	7
2.1.3	Available MZB1 Models with RS-422 Interface	7
2.2	Specifications of the FS-422 Series	8
2.3	Pin Assignment of the RJ45 Connector	8
2.3.1	Connecting the Tension Meter	8
2.4	Optional Accessories	9
2.5	Delivery Includes	9
2.6	Unpacking	9
3	Initial Setup and Operating Procedure	9
3.1	Notes Before Starting Measurement	9
3.2	Mounting possibilities	10
3.3	Setting the Sensor Addresses	10
3.4	Connecting the Sensors	10
3.5	Internal Adjustment of the Sensors	12
3.5.1	ZERO Adjustment	13
3.5.2	GAIN Adjustment	14
4	Service and Maintenance	14
4.1	Rollers	14
5	Cleaning	14
6	Verification Interval	14
6.1	Verification of Calibration and Determination of Repair Costs	15
7	Correspondence	16
8	Repairs	16

1 Warranty and Liability

In principle, the supply of the device is subject to our "General Conditions of Sale and Delivery." These have been provided to the operating company on conclusion of the contract, at the latest.

Warranty:

- SCHMIDT tension meters are warranted for 12 months.

Parts subject to wear, electronic components and measuring springs are not covered by the warranty. No warranty or liability will be accepted for bodily injury or property damage resulting from one or several of the following causes:

- Misuse or abuse of the device.
- Improper mounting, commissioning, operation and maintenance of the device (e.g. verification interval).
- Operation of the device if any safeguards are defective or if any safety and protection precautions are not properly installed or not operative.
- Failure to comply with the notices in the Operating Instructions regarding transport, storage, mounting, commissioning, operation, maintenance and setup of the device.
- Any unauthorized structural alteration of the device.
- Insufficient inspection of device components that are subject to wear.
- Opening the device or improper repair work.
- Disasters caused by the effects of foreign objects or by force majeure.

1.1 Notices within the Operating Instructions

The fundamental prerequisite for the safe handling of this device and its troublefree operation is the knowledge of the basic safety notices and safety instructions.

These Operating Instructions contain the most important notices for the safe operation of the device.

These Operating Instructions, in particular the safety notices, must be observed by any person who works with the device. In addition, the applicable local rules and regulations for the prevention of accidents must be complied with.

The representations within the Operating Instructions are not true to scale.

The dimensions given are not binding.

General indications of direction, such as FRONT, REAR, RIGHT, LEFT apply when viewing the front of the device.

1.2 Responsibilities of the Operating Company

In compliance with the EC Directive 89/655/EEC, the operating company agrees to only permit persons to work with the device who:

- are familiar with the basic regulations on industrial safety and accident prevention and who have been trained in handling the device.
- have read and understood the chapter on safety and the warning notices in these Operating Instructions and have confirmed this with their signatures.
- are examined regularly on their safe and conscientious working method.

1.3 Responsibilities of the Personnel

All persons who work with the device agree to perform the following duties before starting work:

- to observe the basic regulations on industrial safety and accident prevention.
- to read the chapter on safety and the warning notices in these Operating Instructions and to confirm with their signatures that they have understood them.

1.4 Informal Safety Measures

The Operating Instructions must always be kept on hand where the device is operated. Apart from the Operating Instructions, the applicable general and local regulations on accident prevention and environmental protection must be provided and complied with.

1.5 Training of the Personnel

Only trained and instructed personnel is permitted to work with the device. The responsibilities of the personnel must be clearly defined for mounting, commissioning, operation, setup, maintenance, and repair. Trainees may only work with the device under the supervision of experienced personnel.

1.6 Intended Use

The device is intended exclusively to be used as a tension meter.

Any other use or any use exceeding this intention will be regarded as misuse.

Under no circumstances shall HANS SCHMIDT & Co GmbH be held liable for damage resulting from misuse.

The intended use also includes:

- Complying with all notices included in the Operating Instructions and observing all inspection and maintenance works.

1.7 Dangers in Handling the Device

The device has been designed according to the state of the art and the approved safety standards. Nevertheless, its use may cause serious or fatal injury to the user or third persons, and/or an impairment of the device or of other material assets.

The device may only be applied:

- For its intended use in a faultless condition with regard to the safety requirements.
- Malfunctions that could impair safety must be remedied immediately.
- Personal protective equipment must be used according to the EC Directive 89/686/EEC.



The device must not be operated in potential explosive areas and must not come into contact with aggressive substances.

1.8 Copyright

The copyright on these Operating Instructions remains with the company HANS SCHMIDT & Co GmbH.

These Operating Instructions are intended for the operating company and its personnel only. They contain instructions and notices that may only be reproduced on the prior written permission of

HANS SCHMIDT & Co GmbH

and under indication of the complete reference data.

Violations will be prosecuted.

1.9 Declaration of Conformity, RoHs II and WEEE Registration

In compliance with the EU Directives 2014/30/EU and 2011/65/EU



HANS SCHMIDT & CO GmbH is registered in compliance with the German Electrical and Electronic Equipment Act (ElektroG) under WEEE Reg. No. DE 48092317.

2 Available Models

2.1 General Information


These Operating Instructions refer to the MZ1-422 Model of the MZ Series; they are also applicable to the following models: MZH-422, MZB1-422

The individual models of the MZ Series are also available with the following modifications (customized versions):


- Customized measuring head width
- Special tension ranges
- Customized roller dimensions and materials
- Customized distance between outside guide rollers
- Special calibration using customer supplied material

The Operating Instructions can also be used for these instruments as their handling is the same.

Model Numbers:



2.1.1 Available MZ Models with RS-422 Interface



Model with Tension Range	Tension Range [cN]	*Measuring Head Width [mm]	**Schmidt Calibration Material
MZ1-1000-422	0 - 1000	124	PA: 0.30 mm Ø
MZ1-2000-422	0 - 2000	124	PA: 0.50 mm Ø
MZ1-5000-422	0 - 5000	124	PA: 0.80 mm Ø
MZ1-10K-422	0 - 10 daN	124	PA: 1.00 mm Ø


MZ1 Guide Rollers:

V-Groove	Line Speed [m/min ... max.]	Roller Material
Standard	2000	Hard-coated aluminium
Code K	3500	Hard-coated aluminium
Code H	5000	Plasma-coated aluminium
Code ST	1000	Hardened steel
Code B	1000	Heat-treated steel, specially for measuring tire cord
Code CE2	1000	Ceramic
Asymmetrical Groove	1000	Hard-coated aluminium
Code ASY		
Code ASYB	1000	Heat-treated steel
U-Groove	2000	Hard-coated aluminium
Code U		

- * Outer dimensions of front plate.
- ** Suitable for 95% of applications. PA = Polyamide Monofilament
Should the process material differ significant from the SCHMIDT calibration material in size, rigidity or shape, we recommend special calibration using customer supplied material.

International unit of tensile force: 1 cN = 1.02 g = 0.01 N
 1 daN = 1.02 kg = 10.00 N

2.1.2 Available MZH Models with RS-422 Interface




Model with Tension Range	Tension Range [cN]	*Measuring Head Width [mm]	**Schmidt Calibration Material
MZH-1000-422	0 - 1000	150	PA: 0.30 mm Ø
MZH-2000-422	0 - 2000	150	PA: 0.50 mm Ø
MZH-5000-422	0 - 5000	200	PA: 0.80 mm Ø
MZH-10K-422	0 - 10 daN	200	PA: 1.00 mm Ø
MZH-20K-422	0 - 20 daN	250	PA: 1.50 mm Ø
MZH-50K-422	0 - 50 daN	250	Steel rope 1.50 mm Ø (7 x 7 x 0.20)
MZH-100K-422	0 - 100 daN	250	Steel rope 3.00 mm Ø (6 x 7 x 0.30)

MZH Guide Rollers:

V-Groove	Line Speed [m/min ... max.]	Roller Material
Standard	4000	Hardened steel (max. 4 mm Ø)
U-Groove Code R1	4000	Hard chromed-plated steel (3 - 9 mm Ø) Model MZH-5000 and higher
Code R4	1000	Hardened steel (8 - 11 mm Ø) Model MZH-50K and higher
Code R5	1000	Hardened steel (12 - 15 mm Ø) Model MZH-50K and higher
flat Code B6	2000	Hardened steel, width 6 mm
Code B10	2000	Hardened steel, width 10 mm

2.1.3 Available MZB1 Models with RS-422 Interface



Model with Tension Range	Tension Range [cN]	*Measuring Head Width [mm]	Roller Widths
MZB1-1000-422	0 - 1000	120	7, 10, 15, 20
MZB1-2000-422	0 - 2000	120	7, 10, 15, 20
MZB1-5000-422	0 - 5000	120	7, 10, 15, 20
MZB1-10K-422	0 - 10K	120	7, 10, 15, 20

MZB1 Guide Rollers:

V-Groove	Line Speed [m/min ... max.]	Roller Material
Standard	1000	Hard-coated aluminium

* Outer dimensions of front plate.


** Suitable for 95% of applications. PA = Polyamide Monofilament

Should the process material differ significant from the SCHMIDT calibration material in size, rigidity or shape, we recommend special calibration using customer supplied material.
International unit of tensile force: 1 cN = 1.02 g = 0.01 N - - 1 daN = 1.02 kg = 10.00 N

2.2 Specifications of the MZ-422 Series

Calibration:	According to SCHMIDT factory procedure
Accuracy:	± 1% FS* and ± 1 digit or better Other calibration material: ± 3% FS* or better
Overload Protection:	100% of range
Measuring Principle:	Strain gauge bridge
Meas. Roller Deflection:	0.5 mm, max.
Natural Frequency of Measuring Spring:	Approx. 500 Hz, depending on tension range
Signal Processing:	Digital 12-bit A/D converter, sampling rate approx. 4800 /s Internal averaging up to 4 s
Communication Frequency:	Approx. 200 readings /s
Output Signal:	RS-422 (57600 baud, 8 bits, no parity, 1 stop bit) ASCII communication, max. cable length 400 m
Temperature Coefficient:	Zero point: less than ± 0.05% FS* / °C
Temperature Range:	10 - 45 °C
Air Humidity:	85% RH, max.
Power Supply:	15 to 24 V DC, 50 mA (regulated)
Housing:	Aluminium

2.3 Pin Assignment of the RJ45 Connector



Pin No.	Signal	Description
1	VCC	Supply voltage
2	GND	Ground (GND)
3	TX+ (Y)	TRANSMITTED DATA +
4	RX- (B)	RECEIVED DATA +
5	RX+ (A)	RECEIVED DATA -
6	TX- (Z)	TRANSMITTED DATA -
7		Not assigned
8		Not assigned

2.3.1 Connecting the Tension Meter

CE The requirements of the CE specification are only complied with if the tension sensor is equipped and operated with display units and connecting cables supplied by HANS SCHMIDT & Co GmbH. Certification to the CE specification does not extend to, and shall be invalid for any other combination. Under no circumstances shall HANS SCHMIDT & Co GmbH be held liable for any damage resulting from the use of non-SCHMIDT sensors or cables.

2.4 Optional Accessories

- Code **SW-TI3**: Tension Inspect 3 software for PC evaluation of readings
Code **SW-TI3-XX**: Tension Inspect 3 software for PC evaluation of readings from up to 24 sensors
Code **EBG-800**: RS-422/RS-232 converter
Code **EK-0715**: Open-ended connection cable (length 3 m) for connection to the RS-422/RS-232 converter
Code **EK-0711**: Sensor-to-sensor connection cable, length 3 m
Code **EK-0712**: Sensor-to-sensor connection cable, length 1.5 m

2.5 Delivery Includes

- 1x Sensor
- 1x Operating Instructions

2.6 Unpacking

Unpack the instrument and inspect it for any shipping damage. Notices of defect must be announced immediately, in writing, at the latest within 7 days on receipt of the goods.

3 Initial Setup and Operating Procedure

3.1 Notes Before Starting Measurement



Tensions that exceed the tension range of the instrument by more than 100% may cause permanent damage to the measuring spring and must be avoided under any circumstances.

HANS SCHMIDT & Co GmbH provides no warranty or liability for self-made cables.



The model number, the serial number, the calibration label (option) and the SCHMIDT Quality Seal are provided on back side of the sensor.

3.2 Mounting possibilities

Sensors of MZ-422 series can be mounted in different ways:

- Mounting by using the two flanges on the side of the housing
- Mounting on a flat platform




fig. 3.2

3.3 Setting the Sensor Addresses

You can connect up to 24 sensor units by cable to the RS-422/RS-232 converter and on to a PC, by using the factory-provided assignment of the CHANNEL NUMBERS.

i The sensor models of the FS-422 series are supplied as complete units, which have been customized for the specific application. The sensor addresses have been factory preset in this case and usually do not need to be changed.

3.4 Connecting the Sensors

- Install the sensor in the desired position at the measuring location using the provided mounting holes (frontplate or housing).
- Connect the sensor(s), the RS-422/RS-232 converter, and the PC.




fig. 3.4a

3.4 Connecting the Sensors




fig. 3.4b

3.4 Connecting the Sensors



The cable length between the last sensor and the converter may be max. 1000 m.

The cable length between the converter and the PC may be max. 10 m

3.5 Internal Adjustment of the Sensors

General information:

If the sensor has been delivered with a display unit, the ZERO and GAIN adjustments should only be carried out with the supplied display unit.

All tension meters are calibrated with standard materials - such as polyamide monofilament (PA) - according to the SCHMIDT factory procedure; the material path is vertical. Any difference in process material size and rigidity from the standard material may cause a deviation of the accuracy.

In 95% of all industrial applications the SCHMIDT calibration has been proven to provide the best results and is used for comparative purposes.

If required you can also operate the sensors with a material path other than vertical.

Should the process material differ significantly from the SCHMIDT calibration material in size, rigidity or shape, we recommend special calibration using customer supplied material. If the material path is other than vertical or if the process material deviates significantly from the SCHMIDT calibration material, you need to carry out static **ZERO** and **GAIN adjustment** as described in Chapters 3.5.1 and 3.5.2.

3.5.1 ZERO Adjustment




fig. 3.3a

fig. 3.3b

fig. 3.3c

- Install the sensor in the desired position at the measuring location using the provided mounting holes.
- Allow approx. 10 minutes for thermal stabilization of the sensor.
- Thread the process material through the measuring and guide rollers, following the material path symbol on the front of the sensor.



When threading the process material through the rollers, follow the material path symbol on the front of the sensor. If a force is applied to the middle sensor roller in the incorrect direction, damage could result.



Since ZERO and GAIN adjustments are always performed statically, the readings may differ under dynamic load.

- Hang a weight that corresponds to e.g. 10 % of the tension range from the process material.
- Start the measuring in the software
- Adjust the potentiometer, which you can reach through the ZERO hole in the housing, with a screwdriver (with a point width of max. 1.9 mm) until the software displays the corresponding value of 10 %,



Do not insert the screwdriver at an angle as this may damage the potentiometer.

3.5.2 GAIN Adjustment

Requirement: ZERO adjustment carried out.

Thread the process material through the measuring and guide rollers, following the material path symbol on the front of the sensor.

- Hang a weight that corresponds to e.g. 95 % of the tension range from the process material.
- Start the measuring in the software
- Adjust the potentiometer, which you can reach through the GAIN hole in the housing, with a screwdriver (with a point width of max. 1.9 mm) until the software displays the corresponding value of 95 %,



Do not insert the screwdriver at an angle as this may damage the potentiometer.

4 Service and Maintenance

The instrument is easy to maintain. Depending on operating time and load, the instrument should be checked according to the applicable local regulations and conditions (as described in Chapter 3.5). The use of other test methods than the procedure described in Chapter 3.5 may cause deviating measuring results.

4.1 Rollers

You should regularly inspect the rollers to assure that they are running easily and smoothly. You can replace the rollers yourself, as necessary. Please indicate the tension meter model and the serial number in your spare-parts order.

5 Cleaning

For cleaning the instrument, do not use any



AGGRESSIVE SOLVENTS

such as trichloroethylene or similar chemicals.



NO WARRANTY OR LIABILITY

shall be accepted for damage resulting from improper cleaning.

6 Verification Interval

The question of finding the right frequency of calibration accuracy verification depends on several different factors:


- Operating time and load of the SCHMIDT tension meter
- Tolerance band defined by the customer
- Changes to the tolerance band compared to previous calibrations

Therefore, the interval between verifications of calibration must be determined by the user's Quality Assurance Department, based on the user's experience.

Assuming normal operating time and load as well as careful handling of the tension meter, we recommend a verification interval of one year.

6.1 Verification of Calibration and Determination of Repair Costs

Flow chart for verifying the calibration of used tension meters, incoming and outgoing verification with Inspection Certificate 3.1 according to DIN EN 10204



7 Correspondence

Should you have any questions regarding the instrument or Operating Instructions, or their use, please indicate above all the following details which are given on the ID plate:

- 1.) Model
- 2.) Serial number

8 Repairs

Shipping instructions:

We kindly ask for return free of charge for us, if possible by airmail parcel. All occurring charges, if any (such as freight, customs clearance, duty etc.), will be billed to customer. For return from foreign countries, we ask you to include a proforma invoice with a low value for customs clearance only, e.g. 50 Euro, each and to advise the shipment in advance by fax or eMail.

1

To avoid unnecessary follow-up questions, and the resulting loss of time or possible misunderstandings, please return the instrument with a detailed fault description to our service department. Please indicate in your order whether you require an Inspection Certificate 3.1 according to DIN EN 10204.

**Service address: HANS SCHMIDT & Co GmbH
Schichtstr. 16
84478 Waldkraiburg
Germany**

More than 70 years - Worldwide -

Hans Schmidt & Co GmbH

Mailing address:

P. O. B. 1154
84464 Waldkraiburg Germany

Shipping address:

Schichtstr. 16
84478 Waldkraiburg Germany

Phone:

int. + 49 / (0)8638 / 9410-0

Fax:

int. + 49 / (0)8638 / 4825

int. + 49 / (0)8638 / 67898

e-mail:

info@hans-schmidt.com

Internet:

<http://www.hans-schmidt.com>