

UT320A

Mini Single Input Thermometer

User Manual

I. Introduction

UT320A single input thermometer accepts Type K and J thermocouples.

Features:

- Wide measurement range
- High measurement accuracy
- Selectable thermocouple K/J.

Warning: For safety and accuracy, please read this manual before use.

II. Open Box Inspection

Open the package box and take out the device. Please check whether the following items are deficient or damaged and contact your supplier immediately if they are.

1. UT-T01----- 1 pcs
2. Battery: 1.5V AAA ----- 3 pcs
3. Plastic holder----- 1 set
4. User manual----- 1

III. Safety Instructions

If the device is used in a manner that is not specified in this manual, the protection provided by the device might be impaired.

- 1) If low power symbol appears, please replace the battery.
- 2) Do not use the device and send it to maintenance if malfunction occurs.
- 3) Do not use the device if explosive gas, steam or dust surrounding.

- 4) Do not input overrange voltage (30V) between thermocouples or between thermocouple and the ground.
- 5) Replace parts with the specified ones.
- 6) Do not use the device when the rear cover is open.
- 7) Do not charge the battery.
- 8) Do not throw the battery to fire or it may explode.
- 9) Identify the polarity of the battery.

IV. Structure

- 1) Thermocouple jacks
- 2) NTC inductive hole
- 3) Front cover
- 4) Panel
- 5) Display screen
- 6) Buttons




Figure 1

V. Symbols




Figure 2

- 1) Average value
- 2) Data hold
- 3) Maximum temperature
- 4) Minimum temperature
- 5) Low power
- 6) Thermocouple type
- 7) Temperature unit
- 8) Auto power off

VI. Buttons and setup

- : short press: power ON/OFF; long press: switch ON/OFF auto shutdown function.
- : short press: switch temperature unit.
- : short press: switch between MAX/MIN/AVG modes. Long press: switch thermocouple type
- : short press: switch ON/OFF data hold function; long press: switch ON/OFF backlight

VII. Operation instructions

- 1) Thermocouple plug
- 2) Contact point
- 3) Object being measured
- 4) Thermometer




Figure 3

1. Connection

- A. Insert thermocouple into input jacks
- B. Short press to turn on the device.
- C. Setup the thermocouple type (according to the type being used)

Note: If the thermocouple is not connected to input jacks, or in open circuit, "----" appears on the screen. If over range occurs, "OL" appears.

2. Temperature display

Short press to select temperature unit.

- A. Place the thermocouple probe on object to be measured.

- B. Temperature is displayed on the screen. Note: It takes several minutes to steady the readings if thermocouples are just inserted or replaced. The purpose is to ensure the accuracy of cold junction compensation

3. Data hold

- A. Short press to hold the data displayed. HOLD symbol appears.
- B. Short press again to switch off data hold function. HOLD symbol disappears.

4. Backlight ON/OFF

- A. Long press to turn on backlight.
- B. Long press again to turn off backlight.

5. MAX/MIN/AVG value

Short press to cycle switch between MAX, MIN, AVG or regular measurement. Corresponding symbol appears for different modes. E.g MAX appears when measuring maximum value.

6. Thermocouple type

Long press to switch thermocouple types (K/J). TYPE:K or TYPE: J are type indicators.

7. Battery replacement




Figure 4

Please replace the battery as figure 4 shown.

VIII. Specifications

Range	Resolution	Accuracy	Remark
-50~1300°C (-58~2372°F)	0.1°C (0.2°F)	±1.8°C (-50°C~0°C) ±3.2°F (-58~32°F)	K-type thermocouple
		±[0.5%rdg+1°C] (0°C~1000°C) ±[0.5%rdg+1.8°F] (-32~1832°F)	
		±[0.8%rdg+1°C] (1000°C~1300°C) ±[0.8%rdg+1.8°F] (1832~2372°F)	
-50~1200°C (-58~2152°F)	0.1°C (0.2°F)	±1.8°C (-50°C~0°C) ±3.2°F (-58~32°F)	K-type thermocouple
		±[0.5%rdg+1°C] (0°C~1000°C) ±[0.5%rdg+1.8°F] (-32~1832°F)	
		±[0.8%rdg+1°C] (1000°C~1300°C) ±[0.8%rdg+1.8°F] (1832~2192°F)	

Table 1

Note: operating temperature: -0~40°C (32~102°F)
(thermocouple error is excluded in specifications listed above)

IX. Thermocouple specifications

Model	Range	Scope of application	Accuracy
UT-T01	-40~260°C (-40~500°F)	Regular solid	±2°C (-40~260°C) ±3.6°F (-40~500°F)

UT-T03	-50~600°C (-58~1112°F)	Liquid, gel	±2°C (-50~333°C) ±3.6°F (-58~631°F)
			±0.0075*rdg (333~600°C) ±0.0075*rdg (631~1112°F)
UT-T04	-50~600°C (-58~1112°F)	Liquid, gel (food industry)	±2°C (-50~333°C) ±3.6°F (-58~631°F)
			±0.0075*rdg (333~600°C) ±0.0075*rdg (631~1112°F)
UT-T05	-50~900°C (-58~1652°F)	Air, gas	±2°C (-50~333°C) ±3.6°F (-58~631°F)
			±0.0075*rdg (333~900°C) ±0.0075*rdg (631~1652°F)
UT-T06	-50~500°C (-58~932°F)	Solid surface	±2°C (-50~333°C) ±3.6°F (-58~631°F)
			±0.0075*rdg (333~500°C) ±0.0075*rdg (631~932°F)
UT-T07	-50~500°C (-58~932°F)	Solid surface	±2°C (-50~333°C) ±3.6°F (-58~631°F)
			±0.0075*rdg (333~500°C) ±0.0075*rdg (631~932°F)

Table 2

Note: Only K-type thermocouple UT-T01 is included in this package.
Please contact the supplier for more models if needed.

UNI-T

UNI-TREND TECHNOLOGY (CHINA) CO., LTD.

No6, Gong Ye Bei 1st Road,
Songshan Lake National High-Tech Industrial
Development Zone, Dongguan City,
Guangdong Province, China
Tel: (86-769) 8572 3888
<http://www.uni-trend.com>