


## Load Cell Model ZD



Model with Amplifier ZTS/ZTA*	Model with Amplifier eZT**	Measuring Range	A	B	C	E	G	I	L	M
ZD-1000N	eZD-1000N	1000 N	36	30	30	21	7	44	78	M12 P1.75
ZD-2000N	eZD-2000N	2000 N								
ZD-5000N	eZD-5000N	5000 N								
ZD-10kN	eZD-10kN	10 kN								
ZD-20kN	eZD-20kN	20 kN	48	38	32	34	12	46	116	M20 P1.5

\* Accuracy  $\pm 0.5$  % full scale

\*\* Accuracy  $\pm 1.2$  % full scale