

24 MZ1 / MZH / MZB1 - 422 Sensor to PC outputs: RS-422

