



TS-Sensor with Display SC-PM-232

outputs: RS 232, analog and alarm



FS - Sensor with Display SC-PM-232

outputs: RS 232, analog and alarm



MZ - Sensor with Display SC-PM-232

outputs: RS 232, analog and alarm

