



TS - Sensor with Display SC-PM Code A3

outputs: analog and alarm



FS - Sensor with Display SC-PM-A3

outputs: analog and alarm



MZ - Sensor with Display SC-PM-A3

outputs: analog and alarm

