


# MZ1 / MZH / MZB1 -USB Sensor to PC

No external power supply is required.  
Outputs: USB



EK0805 USB cable (3m long) with type B Plug and on the other side with standard USB plug (type A)

← USB 2.0 ←

Software: Tension Inspect 3

