#### **Copyright Statement**

© Datapath Ltd., England, 2015

Datapath Limited claims copyright on this documentation. No part of this documentation may be reproduced, released, disclosed, stored in any electronic format, or used in whole or in part for any purpose other than stated herein without the express permission of Datapath Limited.

Whilst every effort is made to ensure that the information contained in this documentation is correct, Datapath Limited make no representations or warranties with respect to the contents thereof, and do not accept liability for any errors or omissions.

Datapath reserves the right to change specification without prior notice and cannot assume responsibility for the use made of the information supplied.

Datapath Limited acknowledges all registered trademarks used within this documentation.

Product	VisionSC-SDI4 Quick Start Guide
Classification	Released

**UK Headquarters** 

Datapath Ltd., Bemrose House, Bemrose Park, Wayzgoose Drive, Derby, DE21 6XQ, United Kingdom

> **Tel:** +44 (0) 1332 294441 **Fax:** +44 (0) 1332 290667

### US Office

Datapath North America 2490 General Armistead Avenue Suite 102 Norristown, PA 19403 USA

Tel: +1 484 679 1553

Email: sales@datapath.co.uk Web: www.datapath.co.uk

## VisionSC-SDI4 3G-SDI Video Capture Card





#### **PACKING LIST**

#### HARDWARE INSTALLATION

#### SOFTWARE INSTALLATION

Your packing box should contain the following items:

The VisionSC-SDI4 - Four Channel 3G-SDI capture card.

(For latest drivers go to www.datapath.co.uk).

#### NOTE:

All plug-in cards are static sensitive and are packed in antistatic materials. Please keep the card in its packaging until you are ready to install.



You are likely to need a flat blade and/or a cross head screwdriver for the installation of the VisionSC-SDI4 card; it would be useful to have these to hand before you begin.

Power down the PC (including peripherals), switch off at the mains and disconnect all the cables connected to the computer, noting the positions for accurate reconnection Remove the PC cover.

Locate a vacant PCIe slot (x4 or higher) on the motherboard and remove the backing plate (retain all screws).

# If in doubt consult your motherboard documentation to correctly identify a PCIe (PCI-express) slot.

Remove the VisionSC-SDI<sub>4</sub> card from its packaging and secure it firmly into the empty PCIe slot.

Screw the VisionSC-SDI4 bracket to the back panel of the PC and replace the cover. Connect the cable(s) (not supplied) distributing the signals to the BNC connectors on the VisionSC-SDI4 card.

Reconnect all cables to the PC.



Download the the required driver **install.exe** from the Support pages on the Datapath website and follow the Installation Wizard instructions as prompted.

is with both the 32bit and 64bit
lows 10, Windows Server 2008 R2
efore continuing this installation.

We suggest that you regularly visit the Datapath web site for information on updated drivers. www.datapath.co.uk

It is strongly recommended that you read the detailed help instructions on completion of the installation. Each help topic may be printed for ease of use.

FLY-VSC-EN1-V1.0